



ar

Rinse &
Hold

Delay



Washing

Drying

Finished

Rinse Aid

Button Lock

Australians love a *dish*lex!

With the first Dishlex dishwashers being welcomed into Australian homes in 1980, the Dishlex name has been synonymous with excellent performance, reliability and great value.

The new range of Dishlex dishwashers continues to provide practical dishcare solutions wrapped in a stylish contemporary design, and is sure to become one of your best kitchen allies.


Dishlex dishwashers are simple, easy to use and great value for money.

designed for you



simple to use controls

The well-designed dial on the DX103 saves time and reduces confusion. Simply rotate it to select your desired program. The DX203 and DX301 feature push button controls with a button for each program.



handy cutlery basket

The grid keeps cutlery separated for better wash results or can be removed for bulkier items.



load sensing

Load sensing optimises your water usage. Each load is assessed and adjusted on a wash by wash basis. The Auto program senses dirt with the turbidity sensor delivering top wash results while optimising use of water and energy. (DX301 only)



wash progress indicator

Keep up to date with the progress and time remaining of the wash through the indicators on the DX301 control panel. The DX103 features *Off*, *Start* and *Finished* indicators and the DX203 *Washing* and *Finished* indicators.



easy-lift upper basket

The top basket height can be easily adjusted to accommodate large plates and platters in the lower basket, even when fully laden. (DX301 only)



multiple wash programs

If time is of the essence the Quick 30 program is perfect for half loads or when you are in a hurry. Alternatively, choose from one of the other 4 programs for the perfect wash.



fold down rack

The fold down rack in the bottom basket allows large items to be placed on the bottom basket. (DX301 only)



delay start

Delay the start of the wash program for 3 or 6 hours (DX203) and 1 to 19 hours (DX301) to suit your lifestyle or take advantage of off-peak electricity rates.



saves water

With today's climate challenges, we need to do what we can to save water. That's why we offer 4-star WELS water rated dishwashers, so you can make a better choice for your future. (DX203 and DX301 only)



peace of mind

The button lock gives you assurance the selected program can't be accidentally changed. (DX203 and DX301 only)



dishlex



DX301WK

DX301SK

DX203WK

DX203SK

DX103WK

DX103SK

model	DX301WK/SK	DX203WK/SK	DX103WK/SK
available finish	white / stainless steel	white / stainless steel	white / stainless steel
fingerprint-resistant stainless steel	- / ✓	- / ✓	- / ✓
water efficiency (WELS) star rating†	4	4	2
water consumption (ltr)	11.9	11.9	17.8
energy star rating	2.5	2.5	2.5
energy consumption – cold water (kWh/yr)	325	325	332
operating noise level dB(A)	48	51	53

features

	DX301WK/SK	DX203WK/SK	DX103WK/SK
installation*	freestanding	freestanding	freestanding
push-button electronic controls	✓	✓	
time remaining display	✓		
wash programme indicator	✓	✓	✓
wash progress indicator	✓	✓	✓
rinse aid indicator	✓	✓	
number of programs	5 (auto, pots, regular eco, quick 30, rinse & hold)	5 (pots, regular plus, regular eco, quick 30, rinse & hold)	5 (pots, regular plus, regular eco, quick 30, rinse & hold)
wash levels	2	2	2
spray arms	2	2	2
bottom basket fold down rack	2		
adjustable upper basket	easy lift	✓	✓
cup shelves	4	2	2
drying system	active dry	residual	residual
delay start	✓ (1 – 19 hrs)	✓ (3 or 6 hrs)	
load sensing	✓	✓	✓
place settings	12	12	12
turbidity sensor	✓		
removable worktop	✓	✓	✓

safety

	DX301WK/SK	DX203WK/SK	DX103WK/SK
button lock	✓	✓	
water safety system	over fill protection + bottom catchment tray	over fill protection + bottom catchment tray	over fill protection + bottom catchment tray
hidden water heater element	✓	✓	✓

dimensions

	DX301WK/SK	DX203WK/SK	DX103WK/SK
h x w x d (mm) excluding removable worktop	820 x 596 x 550	820 x 596 x 550	820 x 596 x 550
h x w x d (mm) including removable worktop	850 x 596 x 610~	850 x 596 x 610~	850 x 596 x 610~
height adjustable feet (mm)	0 – 10	0 – 10	0 – 10

* Freestanding dishwasher's do not need to be secured under a counter. They can remain as a freestanding unit or fit into a cavity, the dishwasher includes a worktop which can be removed if needed to fit under a tight fitting bench top.

~ Depth of product including profile of door and control panel, 610 mm.

† WELS Standard AS/NZS 6400.2005

The descriptors and illustrations in this publication apply to the specific products and models described as at the date of issue. Under our policy of continuous product development, product specifications may change without notice. Prospective purchasers should therefore check with their retailer to ensure this publication correctly describes the products that are being offered for sale. All information supplied is to be used for general reference purposes only and is on the understanding that Electrolux Home Products Pty Ltd will not be liable for any loss, liability or damage of whatever kind arising as a result of reliance on such information. Colours of products illustrated are as close as printing limitations allow.

Warranty

Electrolux Home Products warrants that for domestic applications only, the Dishlex dishwashers featured in this brochure are free from defects in materials and workmanship for two years from the date of first purchase, subject to the conditions set out in the warranty card accompanying the product. These dishwashers are only suitable for domestic or equivalent applications. They are not suitable for applications where health and industry requirements and regulations apply.

© 2009 Electrolux Home Products Pty Ltd ABN 51 004 762 341

Dishlex. We are part of the Electrolux family. Share more of our thinking at www.electrolux.com.au

For more information on the Dishlex range of dishwashers, please visit your retailer, call our customer care team on 1300 363 640, or visit our website www.dishlex.com.au